


Conexión de cable a cable

Conexiones en paralelo horizontal PG/PT.

Calibre del cable		Carga
De paso	Derivación	
6 Alam	6 Alam	25
6	6	25
4	4	32
	6	32
	6 Alam	32
	8	32
8 Alam	8 Alam	32
	2	65
	2 Alam	65
	4	65
	6	45
2 Alam	6 Alam	45
	8	45
	8 Alam	45
	2	65
2	4	65
	6	45
	6 Alam	45
	8	45
	8 Alam	45
	1 Alam	65
1 Alam	1	65
	2	65
	2 Alam	65
	4	65
	6	65
	6 Alam	65
	8	45
	8 Alam	45



Calibre del cable		Carga
De paso	Derivación	
1	1	65
	1 Alam	65
	2	65
	2 Alam	65
	4	65
	6	65
	6 Alam	65
	8	45
	8 Alam	45
1/0 Alam	1/0	90
	1/0 Alam	90
	1	65
	1 Alam	65
	2	65
	2 Alam	65
	4	65
	6	65
	6 Alam	65
	8	65
8 Alam	65	

CALLE VERDIN No. 1708 COL. 8 DE JULIO 1ra y 2da SECCIÓN C.P. 44910 GUADALAJARA, JAL.

TELS: 01 (33) 3162 0939, 01 (33) 3812 5682, 01 (33) 1368 1962 CEL. 044 3314 51 16 12

e-mail: rafael.salazar@relsamex.com moises.salazar@relsamex.com www.relsamex.com

Calibre del cable		
De paso	Derivación	Carga
1/0	1/0	90
	1/0 Alam	90
	1	65
	1 Alam	65
	2	65
	2 Alam	65
	4	65
	6	65
	6 Alam	65
	8	65
2/0	2/0	115
	1/0	115
	1/0 Alam	115
	2	90
	1	90
	1 Alam	90
	4	90
	6	90
	6 Alam	90
	8	65
3/0	3/0	150
	2/0	150
	1/0	115
	1/0 Alam	115
	2	115
	2 Alam	115
	1 Alam	115
	1	115
	4	115
	6	90
6 Alam	90	
8	90	
8 Alam	90	

Calibre del cable		
De paso	Derivación	Carga
4/0 Alam	4/0	200
	4/0 Alam	200
	3/0	200
	2/0	150
	1/0	150
	1/0 Alam	150
	1	150
	1 Alam	150
	2	150
	2 Alam	150
	4	150
	6	90
	6 Alam	90
	8	90
	8 Alam	90
4/0	4/0	200
	4/0 Alam	200
	3/0	200
	2/0	150
	1/0	150
	1/0 Alam	150
	1	150
	1 Alam	150
	2	150
	2 Alam	150
	4	150
	6	90
	6 Alam	90
	8	90
	8 Alam	90

Calibre del cable		
De paso	Derivación	Carga
300	1/0	150